

# **LS9200 User Guide**

**LinkSprite Technologies, Inc.**

---

## Table of Contents

---

<b>1. Foreword</b> .....	3
<b>2. Features</b> .....	3
<b>3. Part and jumper description</b> .....	4
Part description .....	4
LED and Key description.....	4
Jumper description.....	5
<b>4. Running Linux</b> .....	6
Start Linux .....	6
How to use the ping command.....	7
How to use USB flash disk .....	8
How to use NOR flash .....	8
How to use NAND flash.....	8
How to use    HDD.....	8
How to use    SD card.....	9
How to use audio .....	9
<b>5. How To Dowload Program</b> .....	10
Prepare .....	10
Dwnload u-boot to Norflash .....	11
Dwnload Linux kernel to Norflash .....	11
Dwnload filesystem to Norflash .....	11
<b>6. Compiling u-boot..bin and u-boot.gz</b> .....	13
<b>7. Compiling Linux Kernel</b> .....	14
<b>8. Appendix</b> .....	15
Top silkscreen.....	15
Bottom silkscreen.....	16

## 1. Foreword

---

Thank you for choosing LS9200. This guide will introduce the function and application of LS9200 in detail from simple program to embedded LINUX.

## 2. Features

---

### **CPU**

- 180 MHz ARM920T Processor AT91RM
- 16 KBytes data cache and 16 KBytes instruction cache
- MMU Embedded Linux
- DSP Instruction Extensions

### **Memories**

- 16MB NOR Flash    -32MB NAND Flash    -32MB SDRAM

### **Integrated peripheral interfaces**

- 10/100 Mbps Ethernet MAC
- One-ports USB 2.0 full-speed host
- One-ports USB 2.0 full-speed device
- Two 3-wires UARTs(16550 type)
- One full function UARTs(16550 type)
- One RS485 Port
- One CAN Port
- One LCD with black and white
- SD Card Port
- AC' 97 Part

### **General-purpose I/Os (GPIOs)**

- Five independent key
- Two independent LED

### **JTAG Port**

- The JTAG Port allows use other in-circuit emulators

### **Expansion interface**

- Standard IDE slot

### 3. Part and jumper description

#### Part description

Item	label	function
Debug interface	J3	Download, communicattion
3-Wire serial port	J4	Serial communicate
Full function serial port	J2	Serial communicate
Ethernet interface	J9	10M/100M Ethernet
JTAG interface	J13	Emulate, debug
Audio frequency output interface	J1	Audio frequency output
IDE Buss interface	J10	Connect with 2.5" IDE HDD
Power input interface	J16	Power supply
Power switch	J14	Power switch
SD card jack	J6	Connect with SD card
CAN Bus interface	J12	Connect with CAN Buss
RS485 Bus interface	J5	Connect with RS485 Buss
USB device interface	J8	USB device
USB Host interface	J7	USB Host
LCD interface	J11	LCD expansion
Expansion interface	EXT_I0	GPIO expansion

#### LED and Key description

Item	label	feature
HDD work indicator LED	D5	HDD working
CPU usage indicator LED	D6	CPU usage indicator
Independent LED	D7	Independent LED output
Power indicator LED	D8	5V works normally denote
Power indicator LED	D13	3.3V works normally denote
Power indicator LED	D14	1.8V works normally denote
CPU reset button	S6	System reset
Independent key-up	S2	Independent key input
Independent key-down	S1	Independent key input
Independent key-left	S5	Independent key input
Independent key-light	S4	Independent key input
Independent key-enter	S3	Independent key input

## Jumper description

Item	Label (1,2)	1,2 closed	1,2 open
CAN resistance setup	JP3	Income CAN Bus suited resistance	Disconnect resistance
CF card master/slave select	JP5	Income RS485 Bus suited resistance	Disconnect resistance
EEPROM address setup	JP2	0x02 as address	0x00 as address



Designation	Label (1,2,3)	1,2 close	2,3 close
System boot select	JP1	Boot from internal ROM	Boot from NORFLASH
JTAG mode select	JP4	Normal mode	Boundary scan features

## 4. Running Linux


### Start Linux

By using the serial cable, supplied in the LS9200 Evaluation Kit, connect the board to your PC through the **J3** Serial Debug port Connector.

Power-up the Development Kit through the **J16** connector.

Start the HyperTerminal.


The connection can be called DEBUG, for example. Valid by using the "OK" button.




From the "Connection to" window, select the COM port used and valid by using the "OK" button. Set the serial parameters as described below:

- ✧ Bit rate @115 kbps,
- ✧ Data bit @8-bit,
- ✧ Parity NONE,
- ✧ Stop bit equal to 1,
- ✧ Flux control NONE

Reset the board, wait for about 1 minute.



Press the Reset button (S6) on the LS9200board, See the message sent from the board to the HyperTerminal console (Remark: This message can change according to the "U-Boot" evolution). Booting from the external 16-bit flash (JP1 Boot Mode select Jumper on EXT position)



```

arm - HyperTerminal
File Edit View Call Transfer Help
yaffs: passed flags ""
yaffs: Attempting MTD mount on 31.1, "mtdblock1"
yaffs: auto selecting yaffs1
mount: mounting /dev/uba on /mnt/uhost failed: No such file or directory
----- local service -----
eth0: Link now 100-FullDuplex
mcp251x: WAKIF interrupt.
Normal mode setuped. can0: Link Now.
telnetd start...
CS4394 audio driver initialized
at91_lcm_init: setup device success.
----- WWW.SiTEK.COM -----
stlcm_ioctl: ioctl clear_screen_text success.
lcm_ioctl: ioctl writetext success.
lcm_write: lcm_write begin,count is 15.
lcm_write: copy_from_user count :15 in the lcm_write.
lcm_write: writetext in lcm_write begin.
lcm_write: x=0,y=0, WWW.SiTEK.COM
lcm_write: write success in the lcm_write.
lcm_write: write success.
SiTEK login: _
Connected 0:02:58 TTY 115200 8-N-1 SCROLL CAPS NUM Capture Print echo

```

## How to use the ping command

Connect the Ethernet interface (J9) to you PC using Network Cable. Activate the Ethernet link under Linux, by typing the following commands.For stop the ping press ctrl-c keys.

```

[root@5iTEK root]#ifconfig eth0
eth0      Link encap:Ethernet  HWaddr 22:19:78:10:21:99
          inet addr:172.16.0.92  Bcast:172.16.0.255  Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:17 errors:0 dropped:0 overruns:0 frame:0
          TX packets:9 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:1694 (1.6 KiB)  TX bytes:826 (826.0 B)
          Interrupt:24 Base address:0xc000

[root@5iTEK root]#ping 172.16.0.74
PING 172.16.0.74 (172.16.0.74): 56 data bytes
64 bytes from 172.16.0.74: seq=0 ttl=128 time=0.702 ms
64 bytes from 172.16.0.74: seq=1 ttl=128 time=0.489 ms
64 bytes from 172.16.0.74: seq=2 ttl=128 time=0.489 ms
64 bytes from 172.16.0.74: seq=3 ttl=128 time=0.489 ms
64 bytes from 172.16.0.74: seq=4 ttl=128 time=0.489 ms
— 172.16.0.74 ping statistics —
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 0.489/0.531/0.702 ms64 bytes from 192.168.0.103: icmp_seq=5 ttl=128
time=0.4 ms

```

## How to use USB flash disk

```
[root@5iTEK root]#usb 1-1: new full speed USB device using at91_ohci and address 3
usb 1-1: configuration #1 chosen from 1 choice
 uba: unknown partition table
[root@5iTEK root]#mount -t vfat /dev/uba /mnt/uhost/
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	7931	6294	1637	79%	/
/dev/root	7931	6294	1637	79%	/
/dev/uba	1003056	748576	254480	75%	/mnt/uhost

## How to use NOR flash

```
[root@5iTEK root]#mount -t jffs2 /dev/mtdblock0 /mnt/jffs2/
[root@5iTEK root]#df
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	7931	6294	1637	79%	/
/dev/root	7931	6294	1637	79%	/
/dev/uba	1003056	748576	254480	75%	/mnt/uhost
/dev/mtdblock0	10240	516	9724	5%	/mnt/jffs2

## How to use NAND flash

```
[root@5iTEK root]#mount -t yaffs /dev/mtdblock1 /mnt/yaffs/
[root@5iTEK root]#df
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	7931	6294	1637	79%	/
/dev/root	7931	6294	1637	79%	/
/dev/uba	1003056	748576	254480	75%	/mnt/uhost
/dev/mtdblock0	10240	516	9724	5%	/mnt/jffs2
/dev/mtdblock1	65536	4220	61316	6%	/mnt/yaffs

## How to use HDD

```
[root@5iTEK root]#mount -t vfat /dev/hda1 /mnt/hd/
[root@5iTEK root]#df
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	7931	6294	1637	79%	/
/dev/root	7931	6294	1637	79%	/
/dev/uba	1003056	748576	254480	75%	/mnt/uhost
/dev/mtdblock0	10240	516	9724	5%	/mnt/jffs2
/dev/mtdblock1	65536	4220	61316	6%	/mnt/yaffs
/dev/hda1	10233752	6914312	3319440	68%	/mnt/hd



## How to use SD card

```
[root@5iTEK root]#mount -t vfat /dev/mmcblk0p1 /mnt/sdcard/
```

```
[root@5iTEK root]#df
```

Filesystem	1k-blocks	Used	Available	Use%	Mounted on
rootfs	7931	6294	1637	79%	/
/dev/root	7931	6294	1637	79%	/
/dev/uba	1003056	748576	254480	75%	/mnt/uhost
/dev/mtdblock0	10240	516	9724	5%	/mnt/jffs2
/dev/mtdblock1	65536	4220	61316	6%	/mnt/yaffs
/dev/hda1	10233752	6914312	3319440	68%	/mnt/hd
/dev/mmcblk0p1	991488	20992	970496	2%	/mnt/sdcard

## How to use audio

```
[root@5iTEK root]#cd /mnt/yaffs
```

```
[root@5iTEK root]#madplay moon.mp3
```


```
MPEG Audio Decoder 0.15.2 (beta) - Copyright (C) 2000-2004 Robert Leslie et al.
```

## 5. How To Download Program


### Prepare

Connect the board to your PC through the **J3 Serial Debug port Connector**.


Configure Hyper Terminal is the same with Chapter 4. Boot from internal ROM (JP1 Boot Mode select Jumper on INT position). Power on and push reset button (S6). Then 'C' is appearance continuing on the Hyper Terminal.




send loader.bin by clicking "Transfer->send file..."



send u-boot.bin by clicking "Transfer->send file..."



Then you will see “U-BOOT>”, Waiting your input.



```
arm - HyperTerminal
File Edit View Call Transfer Help
AT91RM9200 loader 0.1 (Jun 10 2007 - 13:10:56)
XMODEM: Download u-boot.bin (to address 21F00000)
CCCCC
!u-boot.bin downloaded successfully

U-Boot 1.3.4 (Apr 14 2009 - 00:33:10)

DRAM: 32 MB
Flash: 16 MB
NAND: 64 MB
env_relocate[227] offset = 0x0
env_relocate[245] malloced ENV at 21ec0230
In: serial
Out: serial
Err: serial
Hit any key to stop autoboot: 0
U-BOOT>
```

Connect the board to your PC through the J9 RJ45 port Connector.

### Download u-boot to Norflash

```
U-BOOT> protect off 10000000 1001ffff
U-BOOT> erase 10000000 1001ffff
U-BOOT> tftp 20000000 boot.bin
U-BOOT> cp.b 20000000 10000000 20000
U-BOOT> protect on 10000000 1001ffff
```

```
U-BOOT> protect off 10020000 1003ffff
U-BOOT> erase 10020000 1003ffff
U-BOOT> tftp 20000000 u-boot.gz
U-BOOT> cp.b 20000000 10020000 20000
U-BOOT> protect off 10020000 1003ffff
```

### Download Linux kernel to Norflash

```
U-BOOT> protect off 10060000 1025ffff
U-BOOT> erase 10060000 1025ffff
U-BOOT> tftp 20000000 ulmage
U-BOOT> cp.b 20000000 10060000 200000
U-BOOT> protect on 10060000 1025ffff
```

### Download filesystem to Norflash

```
U-BOOT> protect off 10260000 1055ffff
U-BOOT> erase 10260000 1055ffff
```

```
U-BOOT> tftp 20000000 ramdisk.gz  
U-BOOT> cp.b 20000000 10260000 300000  
U-BOOT> protect on 10260000 1055ffff
```

At last, JP1 Boot Mode select Jumper on EXT position and Press reset button(S6).

---

## 6. Compiling u-boot..bin and u-boot.gz

---

### Install ARM-LINUX-GCC

If you have not installed ARM-LINUX-GCC, copy file “arm-linux-gcc-4.1.1-920t.tar.bz2” under the file “arm” to the file “/” at the root directory of Linux. Install “arm-linux-gcc” in the file “/usr/local/arm” .  
“tar -jxvf arm-linux-gcc-4.1.1-920t.tar.bz2”.

### Configure U-Boot

Download U-Boot source code “u-boot-1.3.4.tar.bz2” to a catalog of Linux, decompress it by “tar -jxvf u-boot-1.3.4.tar.bz2”.

```
#tar -jxvf u-boot-1.3.4.tar.bz2
```

Run the following command to configure 9200 at the directory of source code

```
#make at91rm9200dk_config  
#make dep
```

Run command “make” to compile

```
#make  
#gzip -c u-boot.bin > u-boot.gz
```

---

## 7. Compiling Linux Kernel

---

### Install ARM-LINUX-GCC

If you have not installed ARM-LINUX-GCC, copy file “arm-linux-gcc-4.1.1-920t.tar.bz2” under the file “arm” to the file “/” at the root directory of Linux. Install “arm-linux-gcc” in the file “/usr/local/arm” .  
“tar -jxvf arm-linux-gcc-4.1.1-920t.tar.bz2”.

### Configure LINUX

Download kernel source code “linux-2.6.23.17.tar.bz2” to a catalog of Linux, decompress it by “tar -zxvf linux-2.6.23.17.tar.bz2”

```
#tar -jxvf linux-2.6.23.17.tar.bz2
```

Configure the kernel by inputting “make menuconfig”


```
#make menuconfig
```

compile kernel


```
#!/mkimage -A arm -O linux -C none -T kernel -a 20008000 -e 20000000 -n linux-2.6 -d arch/arm/boot/zImage ulmage
```

## 8. Appendix

### Top silkscreen



Bottom silkscreen





**LinkSprite Technologies, Inc.**

**Add:** 1410 Cannon Mountain Dr, Longmont, CO 80503

**Tel:** 720-204-8599

**Email:** [sales@linksprite.com](mailto:sales@linksprite.com)

**Technical questions:** [support@linksprite.com](mailto:support@linksprite.com)

**Web:** [www.linksprite.com](http://www.linksprite.com)